


SACE Tmax XT


PB - Separatori di fase XT1-XT2-XT3-XT4
 PB - Phase barriers XT1-XT2-XT3-XT4
 PB - Trennwände zwischen den Phasen XT1-XT2-XT3-XT4
 PB - Séparateurs de phase XT1-XT2-XT3-XT4
 PB - Separadores de fase XT1-XT2-XT3-XT4
 PB - 相间隔板XT1-XT2-XT3-XT4

XT1-XT2-XT3-XT4




	III	IV	III	IV	III	IV
XT1	4	6	4	6	4	6
XT3	4	6	4	6	4	6

	III	IV	III	IV	III	IV
XT2	4	6	4	6	4	6
XT4	4	6	4	6	4	6




A

XT1 - XT3




B

XT1 - XT3




C

XT1 XT3/EF




D

XT1 - XT3/ F / ES




E

XT1 - XT3/P




F

XT1 - XT3




G

XT1 - XT3/ Fc Cu Al/ P




H

XT1 - XT3




I

ONLY FOR XT2 F- XT4 F




J

XT2 - XT4




K

XT2 - XT4/EF




L

XT2 - XT4/ES




M

XT2 - XT4




N

XT2 - XT4



O

XT2 - XT4



P

XT2 - XT4

